




# ASSEMBLY INSTRUCTIONS

## H6ARM: MALIBU BENCH ARMRESTS

**\*\*IF YOU ARE ADDING THE ARMRESTS TO AN EXISTING BENCH- COMPLETE THESE STEPS 1<sup>ST</sup>:**

- a) Place the armrest on the bench leg so that the metal bracket is flat on the bench leg and flush with the back of the bench, making sure the metal bracket is centered on the leg.
- b) Mark the hole locations and drill a hole through the bench leg using a 5/16" bit.
- c) On the backside and underside of the bench leg you will then need to use the holes you just drilled as a guide to countersink the hole using a 7/8" bit. The hole needs to be countersunk approximately 3/4" deep.

REF#	QTY	DESCRIPTION
1	2	ARMRESTS
	<b>H6ARM</b>	<b>HARDWARE KIT</b>
2	4	 5/16" x 3 1/2" CARRIAGE BOLT
3	4	 5/16" SS FLAT WASHER
4	4	 5/16" SS HEX NUT

**STEP 1:** ALIGN HOLES IN ARMREST WITH THE HOLES IN THE BACK AND SEAT OF THE BENCH LEG. INSERT CARRIAGE BOLTS AND SECURE WITH 5/16" WASHER AND NUT.

**STEP 2:** REPEAT FOR OTHER ARMREST.

**STEP 3:** TIGHTEN ALL NUTS. BE CAREFUL NOT TO OVER TIGHTEN.

*Your 100% recycled plastic bench will give you many years of pleasure and pride,  
knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.*

